CLEENOL GROUP LTD

PRODUCT USE GUIDE FOR

CLEENOL SPRAY ON DEGREASER

Product Description

A product that forms part of the Catering Hygiene Programme. Designed for the effective removal of caramelised grease from cookers, extractor fittings and canopy hoods. Also for external areas of fat fryers, cook and hold ovens and other cooking appliances.

Product Features

- A simply spray on and wipe off application to remove grease and dirt from metals, plastics and ceramic tiles.
- Especially useful for the removal of rubber heel marks from hard floors.

Directions for Use

- Use undiluted or diluted up to 1:5 with water, depending upon the build-up of grease and dirt.
- Spray onto the surface to be cleaned and wipe off after a few seconds with a clean damp cloth.
- Rinse cloth frequently in clean water.
- Test delicate painted surfaces before general use.

Shelf Life

- It is recommended that this product is used within 12 months of purchase. Do not allow to freeze.

Environmental Hazards

- Do not allow neat liquid to enter surface waterways as ecological damage may be caused.
- In the event of a large spillage, contact the local water authority or Environment Agency immediately.

Packaging

5 litres

750ml

Code Nos.

010402X5	2x5 litres
010475	6x750ml

Data Sheet No. K12

Note: This product is only to be used for the purpose for which it was intended and in accordance with the specified instructions. This product should never be mixed with other chemical products and should be handled with care and stored carefully out of reach of children.

Cleenol Group Limited
Neville House, Beaumont Road, Banbury, Oxon, OX16 1RB, UK.
Tel: +44 (0)1295 251721 Fax: +44 (0)1295 269561
Email: sales@cleenol.co.uk
www.cleenol.co.uk

Certificate No. 316
Certificate No. E3539